



MONOLIT FIRMWARE UPDATE GUIDE

1. Connect MONOLIT to your computer

Use a USB cable to connect MONOLIT to your laptop or computer.

2. Open the update menu

On the MONOLIT device, go to Settings and select Firmware Update.

Note: You can also access update mode by holding the left black button below the screen while plugging in the USB cable.

3. MONOLIT will appear as an external drive

After entering firmware update mode, MONOLIT will appear on your computer as a removable drive. Open this drive.

4. Update the firmware file

In the main folder of the drive, locate the file named monolit.bin.

Delete monolit.bin from the MONOLIT drive.

After deleting it, copy the new firmware file to the same location.

Do not try to overwrite the old file. It must be removed first.

5. Complete the update

MONOLIT will automatically reboot after the new file is copied.

Do not disconnect the cable until the reboot is complete.

MONOLIT ファームウェア更新ガイド

1. MONOLITをパソコンに接続する

USBケーブルでMONOLITをパソコンに接続します。

2. アップデートメニューを開く

設定からFirmware Updateを選択します。

画面下の左側の黒いボタンを押したままUSBケーブルを接続すると、アップデートモードに入ります。

3. MONOLITが外部ドライブとして表示される

アップデートモードに入ると、MONOLITは外部ドライブとしてパソコンに表示されます。

このドライブを開いてください。

4. ファームウェアファイルを更新する

ドライブ内のmonolit.binを探します。

monolit.binを削除してください。

削除後、新しいファイルを同じ場所にコピーします。

上書きせず、必ず先に削除してください。

5. アップデートを完了する

新しいファイルのコピーが終わると、MONOLITは自動的に再起動します。

再起動が終わるまでUSBケーブルを抜かないでください。